


Product Description



Recessed Live-end connector cover

Instruction Manual

single-phase current 220V
 three-phase current 380V
 Support for single/three-phase grids

OFF

20mm

PRO-R4XX-W
 PRO-R4XX-B
 PRO-R4XX-S
 XX:10,20,30

Attention

Wiring diagram

L3 N
 L2 L1

PRO-0431L-W
 PRO-0431L-B
 PRO-0431L-S
 PRO-0431R-W
 PRO-0431R-B
 PRO-0431R-S

PRO-R431-W
 PRO-R431-B
 PRO-R431-S

1. 2. 3.

Troubleshooting

If the track system is out of power, or the voltage value is abnormal, please check whether the following abnormal conditions exist in the installation:

1. Please ensure the direction of Live end "L" or "R" is installed correctly, and ensure the "concave" is aligned with the "convex" stripe in the track;
2. Please ensure the Live end "L" or "R" is installed into the track and the copper flaps are connected to the copper wires;
3. Please ensure the terminals "N" "L1" "L2" "L3" "G" inside of Live end are wired correctly and firmly;

Exceptions

1. During installation, the connector's "concave" groove must be not reversed with the "convex" stripe in the track, otherwise It may cause no power for one phase, and has the risk of overvoltage damage for 3 phases;
2. It is recommended to use the original track system. Compatibility with other track system is not guaranteed;
3. The product is only suitable for indoor, not outdoor;
4. Do not apply paint or glue to the product;